

Installation & Operation Manual

KBAC SERIES

Adjustable Frequency Drives for 3-Phase AC Motors
NEMA-4X / IP-65


Variable Speed / Soft-Start AC Motor Drive
with Electronic Motor Overload Protection for Inverter Duty Motors¹

Washdown and Watertight for Indoor and Outdoor Use

Rated for 208 – 230 and 400/460 Volt 50 & 60 Hz

3-Phase & PSC² AC Induction Motors from Subfractional thru 5 HP

Operates from 115, 208/230 Volt and 400/460 Volt 50/60 Hz AC Line^{2,3}



This Manual Covers Models KBAC-24D, 27D, 29, 45, 48



See Safety Warning,
on page 5.



**NOTE: THE DRIVE IS FACTORY SET FOR
60 Hz MOTORS. FOR 50 Hz MOTORS,
SEE SECTION 6.4, ON PAGE 17.**

The information contained in this manual is intended to be accurate. However, the manufacturer retains the right to make changes in design which may not be included herein.

Notes: 1. UL approved as an electronic overload protector for motors. 2. Special software is available – contact our Sales Department. 3. Do not use this drive with GFCIs. 4. Installation of a CE approved RFI filter is required.



Automation and Control

© 2008 KB Electronics, Inc.
(see back cover)

TABLE OF CONTENTS

Section	Page
1 Quick-Start Instructions	4
2 Safety Warning	5
3 Introduction	6
4 Important Application Information	12
5 Wiring Instructions	13
6 Setting Selectable Jumpers	16
7 Mounting Instructions	19
8 Recommended High Voltage Dielectric Withstand Testing (Hi-Pot Testing)	19
9 Drive Operation	21
10 AC Line Fusing	21
11 Diagnostic LEDs	21
12 Trimpot Adjustments	22
Limited Warranty	28

Tables	Page
1 Jumper Selectable Features	8
2 Optional Accessories	8
3 General Performance Specifications	10
4 Electrical Ratings	10
5 Terminal Block Wiring Information	13
6 Drive Operating Condition and Run/Fault Relay Contact Status	16
7 Drive Operating Condition and Status LED Indicator	22

Figures	Page
1 Quick-Start Connection Diagram	4
2 Control Layout	9
3 Model KBAC-24D Mechanical Specifications	11
4 Models KBAC-27D, 29, 45, 48 Mechanical Specifications	11
5 Maximum Allowed Motor Torque vs. Speed	12
6 Open Ventilated Motor with External Fan Cooling	12
7 Models KBAC-24D, 27D AC Line Input, Motor, and Ground Connections	13
8 Models KBAC-29, 45, 48 AC Line Input, Motor, and Ground Connections	14
9 Remote Main Speed Potentiometer Connection	14
10 Remote Start/Stop Switch Connection with Normally Open Stop Contact	15
11 Remote Start/Stop Switch Connection with Normally Closed Stop Contact	15
12 Start/Stop Function Eliminated	15
13 Voltage Following Connections	15
14 Enable Circuit Connection	16
15 Run/Fault Relay Output Contacts Connection	16
16 Models KBAC-24D, 27D AC Line Input Voltage Selection (Jumper J1)	16
17 Removing Jumper J1 on Models KBAC-24D, 27D	17
18 Motor Horsepower Selection (Jumper J2)	17
19 Automatic Ride-Through or Manual Restart Selection (Jumper J3)	17
20 60 Hz and 50 Hz Motor Selection (Jumpers J4 and J5)	17
21 Available Torque vs. Output Frequency	18
22 120 Hz and 100 Hz Drive Output Frequency Selection	18
23 Fixed or Adjustable Boost Selection (Jumper J6)	18
24 Regenerative or DC Injection Braking Selection (Jumper J7)	18
25 "Run" or "Fault" Output Relay Operation Selection (Jumper J8)	19
26 Normally Open or Closed Stop Contact Selection (Jumper J9)	19
27 Constant or Variable Torque Selection (Jumper J10)	19
28 I ² t Overload Selection (Jumper J11)	19
29 Typical Hi-Pot Test Setup	20

30 Minimum Speed Trimpot (MIN) Range 22

31 Maximum Speed Trimpot (MAX) Range 22

32 Acceleration Trimpot (ACCEL) Range 22

33 Deceleration Trimpot (DECEL) Range 23

34 DC Injection Brake Trimpot (DECEL) Range 23

35 Slip Compensation Trimpot (COMP) Range 23

36 Current Limit Trimpot (CL) Range 23

37 I²t Trip Time vs. Motor Current 24

38 Boost Trimpot (BOOST) Range 25

39 Run-Stop-Jog Switch Connection 25

40 Jog Trimpot (JOG) Range 25

Items Included In this Package:

Adjustable Frequency Drive, Installation and Operation Manual, Trimpot Adjustment Tool, CE Approved Product Information Card, Warranty Registration Card.

Drive Model Nos. and Part Nos.

Model No.	Part No.	
	Black	White*
KBAC-24D	9987	9988
KBAC-27D	9520	9521
KBAC-29	9528	9529
KBAC-45	9530	9531
KBAC-48	9540	9541

**White FDA approved finish.*

UL Notice

230 VAC Controls

Suitable For Use On A Circuit Capable Of Delivering Not More Than 5 kA RMS Symmetrical Amperes, 230 Volts Maximum.

Use Copper Conductors Rated 75 °C.

Suitable for Operation in a Maximum Surrounding Air Temperature of 40 °C.

460 VAC Controls

Suitable For Use On A Circuit Capable Of Delivering Not More Than 5 kA RMS Symmetrical Amperes, 460 Volts Maximum.

Use Copper Conductors Rated 75 °C.

Suitable for Operation in a Maximum Surrounding Air Temperature of 40 °C.

1 QUICK-START INSTRUCTIONS


Important – You must read these simplified instructions before proceeding. These instructions are to be used as a reference only and are not intended to replace the details provided herein. You must read the Safety Warning on, page 5, before proceeding.

See Figure 1. Also see Section 4 - Important Application Information, on page 12.



WARNING! Disconnect main power before making connections to the drive.

FIGURE 1 – QUICK-START CONNECTION DIAGRAM*



*Layout of Model KBAC-24D varies slightly.

- 1.1 AC LINE INPUT CONNECTION** – Wire the AC line input to Terminal Block TB1. See Section 5.1, on pages 13 – 14.

Application Note: Do not wire this drive to a GFCI. If operation with a GFCI is required, contact our Sales Department.

Note: The rated AC line voltage of the drive must match the actual AC line input voltage. On Models KBAC-24D, 27D, the setting of Jumper J1 must match the AC line input voltage.

Models KBAC-24D, 27D: Designed to accept single-phase (Terminals “L1”, “L2”) AC line input only. Rated for 208/230 Volt AC line input with Jumper J1 set to the “230V” position (factory setting). Rated for 115 Volt AC line input with Jumper J1 set to the “115V” position. See Figure 7, on page 13.

Note: Model KBAC-27D is rated for 1½ HP maximum with 115 Volt AC line input and 2 HP maximum with 208/230 Volt AC line input.

Model KBAC-29: Designed to accept single-phase (Terminals “L1”, “L2”) or 3-phase (Terminals “L1”, “L2”, “L3”) AC line input. Rated for 208/230 Volt AC line input only. See Figure 8, on page 14.

Note: Rated for 2 HP maximum with single-phase AC line input and 3 HP maximum with 3-phase AC line input.

Models KBAC-45, 48: Designed to accept 3-phase (Terminals "L1", "L2", "L3") AC line input only. Rated for 400/460 Volt AC line input only. See Figure 8, on page 14.

- 1.2 AC LINE FUSING** – It is recommended that a fuse(s) or circuit breaker be installed in the AC line. Fuse each conductor that is not at ground potential. For the recommended fuse size, see Table 4, on page 10. Also see Section 10, on page 21.
- 1.3 GROUND CONNECTION** – Connect the ground wire (earth) to the ground screw, as shown in Figure 7, on page 13, and Figure 8, on page 14. See Section 5.2, on page 14.
- 1.4 MOTOR CONNECTION** – Wire the motor to Terminal Block TB1 Terminals "U", "V", "W", as shown in Figure 7, on page 13, and Figure 8, on page 14. (Special reactors may be required for cable lengths over 100 ft. (30 m) – consult our Sales Department.) See Section 5.3, on page 14.
- 1.5 60 Hz and 50 Hz MOTOR OPERATION** – The drive is factory set for 60 Hz 3-phase motor operation (Jumper J5 set to the "60Hz" position). For 50 Hz motor operation, set Jumper J5 to the "50Hz" position. See Section 6.4, on page 17.
- 1.6 START/STOP SWITCH** – The drive is supplied with a prewired Start/Stop Switch to electronically "start" and "stop" the drive, as described in Section 5.5, on pages 14 – 15. This switch must be used to "start" the drive each time the AC line is applied to the drive or to "restart" the drive. Also see Section 6.8, on page 18.
- 1.7 JUMPER SETTINGS** – All jumpers have been factory set for most applications, as shown in Figure 2, on page 9. Some applications require setting of the jumpers in order to tailor the drive for a specific requirement. See Section 6, on pages 16 – 18.
- 1.8 TRIMPOT SETTINGS** – All trimpots have been factory set for most applications, as shown in Figure 2, on page 9. Some applications require adjustment of the trimpots in order to tailor the drive for a specific requirement. See Section 12, on pages 22 – 25.
- 1.9 DIAGNOSTIC LEDs** – After power has been applied, observe the LEDs to verify proper drive operation, as described in Section 11, on pages 21 – 22.

2 SAFETY WARNING

Definition of Safety Warning Symbols



Electrical Hazard Warning Symbol – Failure to observe this warning could result in electrical shock or electrocution.



Operational Hazard Warning Symbol – Failure to observe this warning could result in serious injury or death.



This product should be installed and serviced by a qualified technician, electrician, or electrical maintenance person familiar with its operation and the hazards involved. Proper installation, which includes wiring, fusing or other current protection, and grounding can reduce the chance of electrical shocks, and/or fires, in this product or products used with this product, such as electric motors, switches, coils, solenoids, and/or relays. Do not use this drive in an explosion-proof application. Eye protection must be worn and insulated adjustment tools must be used when working with drive under power. This product is constructed of materials (plastics, metals, carbon, silicon, etc.) which may be a potential hazard. Proper shielding, grounding, and filtering of this product can reduce the emission of radio frequency interference (RFI) which may adversely affect sensitive electronic equipment. It is the responsibility of the equipment manufacturer and individual installer to supply this Safety Warning to the ultimate end user of this product. Be sure to follow all instructions carefully. Fire and/or electrocution can result due to improper use of this product. (SW 1/2006)



This product complies with all CE directives pertinent at the time of manufacture. Contact our Sales Department for Declaration of Conformity. Installation of a CE approved RFI filter is required. See RFI Filters & Chokes Selection Guide D-321 (Part No. A42027) for selection of filters to meet the Industrial or Residential Standard. Additional shielded cable and/or AC line cables may be required along with a signal isolator (SIAC (Part No. 9600)).

3 INTRODUCTION

Thank you for purchasing the KBAC Adjustable Frequency Drive. KB Electronics, Inc. is committed to providing total customer satisfaction by producing quality products that are easy to install and operate. The KBAC is manufactured with surface mount components incorporating advanced circuitry and technology.

The drives are variable speed controls housed in a rugged NEMA-4X / IP-65 washdown and watertight die-cast aluminum enclosure. They are designed to operate 208 – 230 and 400/460 Volt 50 & 60 Hz 3-phase AC induction motors from subfractional thru 5 HP. The sine wave coded Pulse Width Modulated (PWM) output operates at a carrier frequency of 16 kHz which provides high motor efficiency and low noise. Adjustable Linear Acceleration and Deceleration are provided, making the drive suitable for soft-start applications.

Due to its user-friendly design, the KBAC AC drive is easy to install and operate. Tailoring to specific applications is accomplished with selectable jumpers and trimpots, which eliminate the computer-like programming required on other drives. However, for most applications no adjustments are necessary. For more advanced programming, PC based Drive-Link™ software is available.

Main features include adjustable RMS Current Limit and I²t Motor Overload Protection.* In addition, Adjustable Slip Compensation with Static Auto-Tune and Boost provides high torque and excellent load regulation over a wide speed range. Power Start™ delivers over 200% motor torque to ensure start-up of high frictional loads. Electronic Inrush Current Limit (EICL™) eliminates harmful AC line inrush current. A Run/Fault Relay is provided, which can be used to turn on or off equipment or to signal a warning if the drive is put into the Stop Mode or if a fault has occurred. The drive is suitable for machine or variable torque (HVAC) applications. Also, a jumper is provided for selection of Regenerative or DC Injection Braking.

Standard front panel features include Diagnostic LEDs for "Power On" and "Drive Status", a Start/Stop Switch, and a Main Speed Potentiometer. Other features include a Barrier Terminal Block to facilitate wiring of the AC line and motor, adjustable trimpots (MIN, MAX, ACCEL, DECEL, COMP, CL, JOG, BOOST), customer selectable jumpers (Line Voltage (dual voltage models only), Motor Horsepower, Automatic Ride-Through / Manual Start, Motor Frequency, Frequency Multiplier, Fixed/Adjustable Boost, Regenerative / Injection Braking, "Run" or "Fault" Output Relay Operation, NO/NC Stop Contact, Constant/Variable Torque, I²t Overload Selection).

Optional accessories include: Forward-Stop-Reverse Switch, On/Off AC Line Switch, Run-Stop-Jog Switch, Signal Isolator, Auto/Manual Switch, Class "A" AC Line Filter, Multi-Speed Board, Programming Kit, Modbus Communication Module, and Liquidtight Fittings. A connector is provided for easy installation of accessories. Custom software: all models can be factory programmed for applications which require special timing, PLC functions, and GFCI operation – contact our Sales Department.

**UL approved as an electronic overload protector for motors.*

3.1 STANDARD FEATURES

- **Industrial Duty Die-Cast Aluminum Case with Hinged Cover** – Available in black finish or FDA approved white finish.
- **Simple to Operate** – Does not require programming. Uses trimpots and jumpers, which are factory set for most applications.
- **Motor HP Selection Jumper** – Allows the drive to be used on a wide range of motors without recalibration.
- **Diagnostic LEDs** – Power on (POWER) and drive status (STATUS).
- **Run/Fault Relay Output Contacts** – Can be used to turn on or off equipment or to signal a warning if the drive is put into the Stop Mode or a fault has occurred.

- **Start/Stop Switch** – Provides electronic start and stop functions.
- **Barrier Terminal Block** – Facilitates wiring of motor, AC line, and Run/Fault Relay Output Contacts.
- **Jumper Selection of Drive Output Frequency** – Increases the motor speed up to two times the rated RPM.
- **Ride-Through** – Provides smooth recovery to the previous set speed during a momentary power loss (of less than 2 seconds).
- **Holding Torque at Zero Speed** – Resists motor shaft rotation when the drive is in Stop Mode.

***Note:** GFCI Operation – This drive can operate with GFCIs (optional software required) – contact our Sales Department.*

3.2 PERFORMANCE FEATURES

- **Power Start™** – Provides more than 200% starting torque which ensures startup of high frictional loads.
- **Slip Compensation with Static Auto-Tune and Boost** – Provides excellent load regulation over a wide speed range.
- **Speed Range** – 60:1

3.3 PROTECTION FEATURES

- **Motor Overload (I²t) with RMS Current Limit*** – Provides motor overload protection which prevents motor burnout and eliminates nuisance trips.*
- **Electronic Inrush Current Limit (EICL™)** – Eliminates harmful Inrush AC line current during startup.
- **Short Circuit** – Shuts down the drive if a short circuit occurs at the motor (phase-to-phase).
- **Regeneration** – Eliminates tripping due to high bus voltage caused by rapid deceleration of high inertial loads.
- **Undervoltage and Overvoltage** – Shuts down the drive if the AC line input voltage goes above or below the operating range.
- **MOV Input Transient Suppression.**
- **Microcontroller Self Monitoring and Auto Reboot.**

**UL approved as an electronic overload protector for motors.*

3.4 TRIMPOT ADJUSTMENTS

- **Minimum Speed (MIN)** – Sets the minimum speed of the motor. See Section 12.1, on page 22.
- **Maximum Speed (MAX)** – Sets the maximum speed of the motor. See Section 12.2, on page 22.
- **Acceleration (ACCEL)** – Sets the amount of time for the motor to accelerate from zero speed to full speed. See Section 12.3, on page 22.
- **Deceleration (DECEL)** – Sets the amount of time for the motor to decelerate from full speed to zero speed. See Section 12.4, on page 23.
- **DC Injection Brake (DECEL)** – When the drive is set for DC Injection Braking (Jumper J7 set to the "INJ" position), the DECEL trimpot is used to set the DC Injection Brake voltage and time. See Section 12.5, on page 23.
- **Slip Compensation (COMP)** – Maintains set motor speed under varying loads. See Section 12.6, on page 23.
- **Current Limit (CL)** – Sets the current limit (overload) which limits the maximum current to the motor. See Section 12.7, on page 24.
- **Boost (BOOST)** – Sets the amount of Boost which can be used to obtain maximum low speed performance. See Section 12.8, on pages 24 – 25.
- **Jog (JOG)** – Sets the "jog" speed of the motor. Must be used with the optional Run-Stop-Jog Switch Kit (Part No. 9340). See Section 12.9, on page 25.

TABLE 1 – JUMPER SELECTABLE FEATURES

Description ¹	PC Board Designation	KBAC-24D	KBAC-27D	KBAC-29	KBAC-45	KBAC-48
AC Line Input Voltage (115, 230)	J1	✓	✓	—	—	—
Motor Horsepower (see Table 4 - Electrical Ratings, on page 10)	J2	✓	✓	✓	✓	✓
Automatic Ride-Through or Manual Restart (A* , M)	J3	✓	✓	✓	✓	✓
Frequency Multiplier (1X , 2X)	J4	✓	✓	✓	✓	✓
Motor Frequency (50Hz, 60Hz)	J5	✓	✓	✓	✓	✓
Fixed or Adjustable Boost (FIX , ADJ)	J6	✓	✓	✓	✓	✓
Regenerative or DC Injection Braking (RG , INJ)	J7	✓	✓	✓	✓	✓
"Run" or "Fault" Output Relay Operation (R , F)	J8	✓	✓	✓	✓	✓
Normally Open or Closed Stop Contact (NO , NC)	J9	✓	✓	✓	✓	✓
Constant or Variable Torque (VT , CT)	J10	✓	✓	✓	✓	✓
I ² t Overload Selection (1 , 2)	J11	✓	✓	✓	✓	✓

Notes: **1.** Bold indicates factory setting. **2.** In Automatic Ride-Through Mode, the drive will automatically restart due to a momentary power loss of less than 2 seconds.


TABLE 2 – OPTIONAL ACCESSORIES

Description		Model KBAC-24D	Model KBAC-27D	Model KBAC-29	Model KBAC-45	Model KBAC-48
Forward-Stop-Reverse Switch – Provides motor reversing and stop functions. Mounts on the enclosure cover and is supplied with a switch seal to maintain liquidtight integrity.		9480	9480	9480	9480	9480
On/Off AC Line Switch – Disconnects the AC line. Mounts on the enclosure cover and is supplied with a switch seal to maintain liquidtight integrity.		9482	9523	9532	9532	9532
Run-Stop-Jog Switch – Selects speed setting from either the Main Speed Potentiometer or the JOG Trimpot. Mounts on the enclosure cover and is supplied with a switch seal to maintain liquidtight integrity.		9340	9340	9340	9340	9340
Signal Isolator – Provides isolation between a non-isolated signal source and the drive. Mounts on the drive's PC board with four snap-ins.		9600*	9600*	9600*	9600*	9600*
Auto/Manual Switch – When used with the Signal Isolator, it selects remote process signal or the Main Speed Potentiometer. Mounts on the enclosure cover and is supplied with a switch seal to maintain liquidtight integrity.		9481	9481	9481	9481	9481
AC Line Filter ¹ – Provides Class A RFI (EMI) suppression. Installs onto the drive's PC board with quick-connect terminals. Suffix "S": Filter is used when On/Off AC Line Switch is installed. Suffix "NS": Filter is used when On/Off AC Line Switch is not installed.	Suffix "S"	9516	9512	9479	9479	9479
	Suffix "NS"	9507	9512	9515	9515	9515
Multi-Speed Board – Provides multi-speed operation using external contacts or a PLC. Mounts on the drive's PC board with four snap-ins.		9489	9489	9489	—	—
Programming Kit ² – Includes Download Module™ (DLM) handheld programming device which uploads and downloads drive programs, PC to DLM serial communication cable, DLM to drive communication cable, and PC Windows® based Drive-Link™ communication software.		9582	9582	9582	9582	9582
Modbus Communication Module – Allows direct communication between drive and Modbus ³ protocol.		9517	9517	9517	9517	9517
Liquidtight Fittings – Provide a liquidtight seal for wiring the drive. Kit includes three 1/2" and one 3/4" liquidtight fittings		9526	9526	9526	9526	9526

Notes: **1.** Complies with CE Council Directive 89/336/EEC Industrial Standard. **2.** If a USB communication cable is required, purchase Part No. 19008. **3.** Other protocols available – contact our Sales Department.



*** Warning!** It is highly recommended that the Signal Isolator (Part No. 9600) be installed when using the drive with external control signals.

FIGURE 2 – CONTROL I AYOIT¹

Notes: 1. Layout of Model KBAC-24D varies slightly. 2. On Model KBAC-24D, the J0G and COMP Trim pots are located vertically, along the right edge of the PC board (below the mounting screw). 3. On Model KBAC-24D, Jumper J2 is labeled "1", "3/4", "1/2", "1/4". Jumper J2 is labeled "A", "B", "C", "D", "E" factory set to the "1" position. On Models KBAC-29, 45, 48, Jumper J2 is labeled "A", "B", "C", "D", "E" factory set to the "1" position. On Model KBAC-24D, Jumper J2 is labeled "2", "1", "3/4", "1/2" factory set to the "1" position. On Model KBAC-24D, Jumper J2 is labeled "2", "1", "3/4", "1/2" factory set to the "1" position. On Model KBAC-24D, Jumper J2 is labeled "2", "1", "3/4", "1/2" factory set to the "1" position.

TABLE 3 – GENERAL PERFORMANCE SPECIFICATIONS

Description	Specification	Factory Setting
115 Volt AC Line Input Voltage Operating Range (Volts AC)	115 (±15%)	—
208/230 Volt AC Line Input Voltage Operating Range (Volts AC)	208 (-15%) / 230 (+15%)	—
400/460 Volt AC Line Input Voltage Operating Range (Volts AC)	380 (-15%) – 460 (+15%)	—
Maximum Load (% Current Overload for 2 Minutes)	150	—
Carrier, Switching Frequency (kHz)	16, 8	—
Signal Following Input Voltage Range ¹ (Volts DC)	0 – 5	—
Output Frequency Resolution (Bits, Hz)	10, .06	—
Minimum Speed Trimpot (MIN) Range (% Frequency Setting)	0 – 40	0
Maximum Speed Trimpot (MAX) Range (% Frequency Setting)	70 – 110	100
Acceleration Trimpot (ACCEL) and Deceleration Trimpot (DECEL) Range (Seconds)	.3 – 20	1.5
Boost Trimpot (BOOST) Range (Volts/Hz)	0 – 30	5
Slip Compensation Trimpot (COMP) Range at Drive Rating (Volts/Hz)	0 – 3	1.5
Current Limit Trimpot (CL) Range (% Full Load)	40 – 200	160
Jog Trimpot (JOG) Range (% Frequency Setting)	0 – 100	35
Motor Frequency Setting (Hz) (Jumper J5)	50, 60	60
Output Frequency Multiplier (1X, 2X) (Jumper J4) ²	1, 2	1
Minimum Operating Frequency at Motor (Hz)	1	—
Speed Range (Ratio)	60:1	—
Speed Regulation (30:1 Speed Range, 0 – Full Load) (% Base Speed) ³	2.5	—
Overload Protector Trip Time for Stalled Motor (Seconds)	6	—
Undervoltage/Overvoltage Trip Points for 115 Volt AC Line Input (± 5%) (Volts AC) ⁴	76 – 141	—
Undervoltage/Overvoltage Trip Points for 208/230 Volt AC Line Input (± 5%) (Volts AC) ⁴	151 – 282	—
Undervoltage/Overvoltage Trip Points for 400/460 Volt AC Line Input (± 5%) (Volts AC) ⁴	302 – 567	—
Run/Fault Relay Output Contact Rating (Amps at 30 Volts DC, 125 Volts AC, 250 Volts AC)	1, 0.5, 0.25	—
Operating Temperature Range (°C / °F)	0 – 45 / 32 – 113	—


Notes: **1.** Requires an isolated signal. If a non-isolated signal is used, or if using 0 to ±2.5 thru 0 to ±25 Volts DC, or 4 – 20 mA DC signal input, install the SIAC Signal Isolator (Part No. 9600). **2.** Allows the motor to operate up to two times the rated RPM. Constant horsepower will result when operating the drive in the “X2” mode above the motor rated frequency. **3.** Dependent on motor performance. **4.** Do not operate the drive outside the specified AC line input voltage operating range.

TABLE 4 – ELECTRICAL RATINGS

Model No.	Part No.		AC Line Input			Fuse or Circuit Breaker Rating (Amps)	Drive Output			Motor Horsepower Selection ² (Jumper J2)					Net Wt.		
	Black	White ¹	Volts AC (50/60 Hz)	Phase (Φ)	Maximum Current (Amps AC)		Voltage Range (Nominal) (Volts AC)	Maximum Continuous Load Current (RMS Amps/Phase)	Maximum Horsepower (HP (kW))								
	KBAC-24D	9987	9988	115	1		16	20	0 – 230	3.6	1 (.75)	1	3/4	1/2	1/4	1/8	5.9
			208/230	1	10	15	0 – 230										
KBAC-27D	9520	9521	115	1	22	25	0 – 230	5.5	1½ (1.13)	—	1½ ⁴	1	3/4	1/2	10.3	4.7	
			208/230	1	15	20	0 – 230	6.7	2 (1.5)	2 ⁴							
											A	B	C	D	E		
KBAC-29	9528	9529	208/230	1	15	20	0 – 230	6.7	2 (1.5)	—	2 ⁵	1½	1	3/4	10.3	4.7	
				3	10.8	15	0 – 230	9.0	3 (2.25)	3 ⁵							
KBAC-45 ³	9530	9531	400/460	3	5.3	10	0 – 400/460	4.6	3 (2.25)	3	2	1½	1	3/4	10.3	4.7	
KBAC-48 ³	9540	9541	400/460	3	9.6	10	0 – 400/460	8.3	5 (3.75)	5	3	2	1½	1	10.3	4.7	

Notes: **1.** White FDA approved finish. **2.** Bold indicates factory setting. Jumper J2 on Model KBAC-24D is labeled “1”, “3/4”, “1/2”, “1/4”, “1/8” (factory set to the “1” position). Jumper J2 on Model KBAC-27D is labeled “2”, “1½”, “1”, “3/4”, “1/2” (factory set to the “1½” position). Jumper J2 on Models KBAC-29, 45, 48 is labeled “A”, “B”, “C”, “D”, “E” (factory set according to the table). **3.** Models KBAC-45, 48 are rated 0 – 400 Volts AC for 50 Hz motor operation and 0 – 460 Volts AC for 60 Hz motor operation. **4.** Model KBAC-27D is rated 1½ HP maximum with 115 Volt AC line input and 2 HP maximum with 208/230 Volt AC line input. **5.** Model KBAC-29 is rated 2 HP maximum with single-phase AC line input and 3 HP maximum with 3-phase AC line input.


FIGURE 3 – MODEL KBAC-24D MECHANICAL SPECIFICATIONS (INCHES/MM)



Contains 2 mounting holes for standard 1/2" liquidtight fittings

* Tighten these screws, in the sequence shown, to 12 in-lbs (14 kg-cm).

FIGURE 4 – MODELS KBAC-27D, 29, 45, 48 MECHANICAL SPECIFICATIONS (INCHES/MM)



Contains 2 mounting holes for standard 1/2" liquidtight fittings and 1 mounting hole for standard 3/4" liquidtight fitting.

* Tighten these screws, in the sequence shown, to 12 in-lbs (14 kg-cm).

4 IMPORTANT APPLICATION INFORMATION

- 4.1 MOTOR WITH EXTERNAL FAN COOLING** – Most totally enclosed fan-cooled (TEFC) and open ventilated 3-phase AC induction motors will overheat if used beyond a limited speed range at full torque. Therefore, it is necessary to reduce motor load as speed is decreased.

Note: Some fan-cooled motors can be used over a wider speed range. Consult the motor manufacturer for details.


WARNING! Some motors have low speed characteristics which cause overheating and winding failure under light load or no load conditions. If the motor is operated in this manner for an extended period of time, it is recommended that the unloaded motor current be checked from 2 – 15 Hz (60 – 450 RPM) to ensure motor current does not exceed the nameplate rating. **Do not use motor if the motor current exceeds the nameplate rating.**

It is recommended that the drive be used with Inverter Duty or TENV motors.

Inverter duty and most totally enclosed non-ventilated (TENV) motors can provide full rated torque over an extended speed range without overheating. See Figure 5.

If external fan cooling is provided, open ventilated motors can also achieve an extended speed range at full rated torque. A box fan or blower with a minimum of 100 CFM per HP is recommended. Mount the fan or blower so the motor is surrounded by the airflow. See Figure 6.


FIGURE 5 – MAXIMUM ALLOWED MOTOR TORQUE vs. SPEED



4.2 ELECTRONIC MOTOR OVERLOAD PROTECTION

– The drive contains Modified I²t Overload Protection.* Part of this function consists of a Current Limit (CL) circuit, which limits the drive current to a factory preset level of 160% of the rated drive current. The CL Trimpot is used to recalibrate the drive current from 60% thru 200%. The Power Start™ circuit provides an overshoot function that allows most motors to develop more than 200% of starting torque and breakdown torque.

FIGURE 6 – OPEN VENTILATED MOTOR WITH EXTERNAL FAN COOLING



Standard I²t is undesirable because it causes nuisance tripping. It allows a very high motor current to develop and will turn the drive off after a short period of time. KB's RMS Current Limit Circuit avoids this nuisance tripping while providing maximum motor protection.

If the motor is overloaded to 120% of full load (75% of the CL setting), the I²t Timer starts. If the motor continues to be overloaded at the 120% level, the timer will shut down the drive after 30 minutes. If the motor is overloaded to 160% of full load, the drive will trip in 6 seconds.

*UL approved as an overload protector for motors.

5 WIRING INSTRUCTIONS



WARNING! Read Safety Warning, on page 5, before using the drive. Disconnect main power before making connections to the drive. To avoid electric shock, be sure to properly ground the drive. It is highly recommended that the SIAC Signal Isolator (Part No. 9600) be installed when using signal following.

WARNING! Remote connections of potentiometer, switches, etc., will have wiring that is at line potential. It is required that the signal isolator be installed for remote connections.

Application Note – To avoid erratic operation, do not bundle the AC line and motor wires with each other or with wires from signal following, start/stop contacts, or any other signal wires. Also, do not bundle motor wires from multiple drives in the same conduit. Use shielded cables on all signal wiring over 12" (30 cm). The shield should be earth grounded on the drive side only. Wire the drive in accordance with the National Electrical Code requirements and other local codes that may apply.

Be sure to properly fuse each AC line conductor that is not at ground potential. Do not fuse neutral or grounded conductors. A separate AC line switch or contactor must be wired as a disconnect so that each ungrounded conductor is opened. For fuse or circuit breaker selection, see Table 5. Also see Section 10, on page 21.

To maintain the watertight integrity of the drive, be sure to use suitable watertight connectors and wiring which are appropriate for the application. Model KBAC-24D contains two mounting holes for standard 1/2" liquidtight fittings (not supplied) (one watertight plug is provided, if only one knockout is used). Models KBAC-27D, 29, 45, 48 contain two mounting holes for standard 1/2" liquidtight fittings (not supplied) and one mounting hole for standard 3/4" liquidtight fitting (not supplied) (two watertight plugs are provided, if only one knockout is used).

The drive is designed with a hinged case so that when the front cover is open, all wiring stays intact. To open the cover, the four screws must be loosened so they are no longer engaged in the case bottom. After mounting and wiring, close the cover making sure that the wires do not get caught or crimped as the cover is closed. Tighten the four screws so that the gasket is slightly compressed. The recommended tightening torque is 12 in-lbs (14 kg-cm). See Figures 3 and 4, on page 11, for the tightening sequence. Do not overtighten.

TABLE 5 – TERMINAL BLOCK WIRING INFORMATION

Terminal Block	Description	Model	Maximum Wire Size (Cu)		Recommended Tightening Torque	
			AWG	mm ²	in-lbs	kg-cm
TB1	AC Line Input and Motor Wiring	KBAC-24D	12	3.3	7	8
		KBAC-27D, 29, 45, 48	12	3.3	12	14
TB2	Run/Fault Relay Output Contacts	All	16	1.3	3.5	3


5.1 AC LINE INPUT CONNECTION – Wire the AC line input to Terminal Block TB1.

GFCI Operation – Do not connect this drive to an AC power source controlled by a Ground Fault Circuit Interrupter. Special software is available for GFCI operation – contact our Sales Department.

Note: The rated AC line voltage of the drive must match the actual AC line input voltage. On Models KBAC-24D, 27D, the setting of Jumper J1 must match the AC line input voltage.


Models KBAC-24D, 27D: Designed to accept single-phase (Terminals "L1", "L2") AC line input only. Rated for 208/230 Volt AC line input with Jumper J1 set to the "230V" position (factory setting). Rated for 115 Volt AC line input with Jumper J1 set to the "115V" position. See Figure 7.

FIGURE 7 – MODELS KBAC- 24D, 27D*
AC LINE INPUT, MOTOR, AND GROUND CONNECTIONS



*Model KBAC-27D is rated 1/2 HP maximum with 115 Volt AC line input and 2 HP maximum with 208/230 Volt AC line input.

FIGURE 8 – MODELS KBAC-29*, 45, 48 AC LINE INPUT, MOTOR, AND GROUND CONNECTIONS



**Model KBAC-29 is rated 2 HP maximum with single-phase AC line input and 3 HP maximum with 3-phase AC line input.*

Model KBAC-29: Designed to accept single-phase (Terminals “L1”, “L2”) or 3-phase (Terminals “L1”, “L2”, “L3”) AC line input. Rated for 208/230 Volt AC line input only. See Figure 8.

Models KBAC-45, 48: Designed to accept 3-phase (Terminals “L1”, “L2”, “L3”) AC line input only. Rated for 400/460 Volt AC line input only. See Figure 8.

5.2 GROUND CONNECTION – Connect the ground wire (earth) to the Green Ground Screw. The Ground Screw is located next to Terminal Block TB1. See Figure 7, on page 13, and Figure 8.


5.3 MOTOR CONNECTION – Wire the motor to Terminal Block TB1 Terminals “U”, “V”, “W”. See Figure 7, on page 13, and Figure 8. Motor cable length should not exceed 100 ft (30 m) – special reactors may be required – consult our Sales Department.

Be sure Jumper J2 is set to the corresponding motor horsepower rating, as described in Section 6.2, on page 17.

5.4 REMOTE MAIN SPEED POTENTIOMETER CONNECTION – The drive is supplied with a prewired Main Speed Potentiometer mounted on the front cover.

To operate the drive from a remote potentiometer (5 k Ω), remove the white, orange, and violet potentiometer leads from Terminals “P1”, “P2”, and “P3”. The wires may be taped and left inside the drive. The potentiometer assembly may be removed if a watertight seal is used to cover the hole in the front cover. Wire the Main Speed Potentiometer to Terminals “P1” (low side), “P2” (wiper), and “P3” (high side). See Figure 9.

FIGURE 9 – REMOTE MAIN SPEED POTENTIOMETER CONNECTION



WARNING! Do not earth ground any Main Speed Potentiometer terminals.

Application Note – If it is required that the Remote Main Speed Potentiometer be isolated from the AC line, install the SIAC Signal Isolator (Part No. 9600).

5.5 REMOTE START/STOP SWITCH CONNECTION – The drive is supplied with a prewired Start/Stop Switch mounted on the front cover to electronically start and stop the drive.

To operate the drive from a remote Start/Stop Switch (type (ON)-OFF-ON, SPDT), remove the white, black, and red wires from Terminals “RUN”, “COM”, and “STOP”. The wires may be taped and left

inside the drive. The switch assembly may be removed if a liquidtight seal is used to cover the hole in the front cover. After applying power to the drive, momentarily set the Start/Stop switch to the "START" position.

For Start/Stop Switch with normally open stop contact, set Jumper J9 to the "NO" position (factory setting). For Start/Stop Switch with normally closed stop contact, set Jumper J9 to the "NC" position. See Figures 10 and 11. Also see Section 6.8, on page 18.

- 5.6 AUTOMATIC RESTART** – Automatic restart requires the elimination of the Start/Stop Switch. Remove the white, black, and red wires from Terminals "RUN", "COM", and "STOP". The wires may be taped and left inside the drive. The switch assembly may be removed if a liquidtight seal is used to cover the hole in the front cover.

To eliminate the start/stop function, hard-wire Terminals "RUN" and "COM" with the jumper that is provided. Be sure Jumper J9 is set to the "NO" position. See Figure 12.

WARNING! Using a jumper to eliminate the start/stop function will cause the motor to run at the Main Speed Potentiometer setting when the AC line is applied.

- 5.7 VOLTAGE FOLLOWING CONNECTION** – An isolated* 0 – 5 Volt DC analog signal input can also be used to control motor speed in lieu of the Main Speed Potentiometer. The drive output will linearly follow the analog signal input. Wire the signal input positive lead (+) to Terminal "P2" and the negative lead (-) to Terminal "P1". With external circuitry, a 0 – 10 Volt DC analog signal can also be used. See Figure 13.

**If a non-isolated signal is used, install the SIAC Signal Isolator (Part No. 9600). The SIAC accepts voltage (0 to ± 2.5 thru 0 to ± 25 Volts DC) or current (4 – 20 mA DC) signal inputs. See Table 2, on page 8.*

Note: For signal following operation, the Minimum Speed Trimpot (MIN) must be set fully counter-clockwise.



WARNING! The signal input must be isolated from the AC line. Earth grounding signal wiring will damage the drive and void the warranty. It is highly recommended that the SIAC Signal Isolator (Part No. 9600) be installed when using signal following.

- 5.8 ENABLE CIRCUIT CONNECTION** – The drive can also be started and stopped with an Enable circuit (close to run, open to stop). See Figure 14, on page 16.

FIGURE 10 – REMOTE START/STOP SWITCH CONNECTION WITH NORMALLY OPEN STOP CONTACT (J9 Installed in "NO" Position)




FIGURE 11 – REMOTE START/STOP SWITCH CONNECTION WITH NORMALLY CLOSED STOP CONTACT (J9 INSTALLED IN "NC" POSITION)




FIGURE 12 – START/STOP FUNCTION ELIMINATED (TERMINALS HARDWIRED) (JUMPER INSTALLED) (J9 INSTALLED IN "NO" POSITION)






FIGURE 13 – VOLTAGE FOLLOWING CONNECTIONS (ISOLATED)



The Enable function is established by wiring a switch or contact in series with the orange Main Speed Potentiometer lead which connects to Terminal “P2”. When the Enable Switch is closed, the motor will accelerate to the Main Speed Potentiometer setting. When the Enable Switch is opened, the motor will decelerate to stop.

WARNING! If the Enable Switch is to be mounted remotely, it is highly recommended that the SIAC Signal Isolator (Part No. 9600) be installed.

FIGURE 14 – ENABLE CIRCUIT CONNECTION



5.9 Run/Fault Relay Connection – The Run/Fault Relay Output Contacts are located at TB2 and can be used to turn on or off equipment or to signal a warning if the drive is put into the Stop Mode or a fault has occurred. See Figure 15.

The Run/Fault Relay Contact status for various drive operating conditions is shown in Table 6.

FIGURE 15 – RUN/FAULT RELAY OUTPUT CONTACTS CONNECTION




TABLE 6 – DRIVE OPERATING CONDITION AND RUN/FAULT RELAY CONTACT STATUS

Drive Operating Condition	Description	Run Relay Operation (Jumper J8 Installed in “R” Position) (Factory Setting)		Fault Relay Operation (Jumper J8 Installed in “F” Position)	
		Normally Open Contact	Normally Closed Contact	Normally Open Contact	Normally Closed Contact
Power Off	Main Power Disconnected	Open	Closed	Open	Closed
Run Mode*	Normal Drive Operation	Closed	Open	Closed	Open
Stop Mode*	Selected by Operator	Open	Closed	Closed	Open
Fault**	Drive Tripped	Open	Closed	Open	Closed

*Run Mode or Stop Mode is selected using the Start/Stop Switch. **Overload, I²t, Short Circuit, Undervoltage, Overvoltage.

6 SETTING SELECTABLE JUMPERS


The drive has customer selectable jumpers which must be set before the drive can be used. For the location of jumpers, see Figure 2, on page 9.

Note: Disconnect the AC line before changing position of jumpers.

6.1 LINE INPUT VOLTAGE SELECTION (J1 (MODELS KBAC-24D, 27D ONLY)) –

Jumper J1 is factory installed on Terminal “230V” for 208/230 Volt AC line input. For 115 Volt AC line input, the jumper must be removed and installed on Terminal “115V”. See Figure 16.


FIGURE 16 – MODELS KBAC-24D*, 27D AC LINE INPUT VOLTAGE SELECTION



*Layout of Model KBAC-24D varies slightly.

Using pliers, gently rock the female terminal back and forth while pulling it upward. See Figure 17

FIGURE 17 – REMOVING JUMPER J1 ON MODELS KBAC-24D, 27D



- 6.2 **MOTOR HORSEPOWER SELECTION (J2)** – Set Jumper J2 to the corresponding position for the motor being used. See Figure 18.
- 6.3 **AUTOMATIC RIDE-THROUGH OR MANUAL START SELECTION (J3)*** – Jumper J3 is factory set to the “A” position for Automatic Ride-Through. If the power is interrupted for up to 2 seconds, the drive will shut down and then “ride-through” and automatically return to the set frequency. If Jumper J3 is set to the “M” position, the drive will have to be manually restarted for a momentary power loss using the Start/Stop Switch. See Figure 19. Also see Section 11.2, on page 22, for the Status (ST) LED indication.

**On Model KBAC-24D, Jumper J3 is labeled “AUTO” and “MAN”.*

- 6.4 **60 Hz AND 50 Hz MOTOR OPERATION AND DRIVE OUTPUT FREQUENCY SELECTION (J4 AND J5)** – Both jumpers must be set for the appropriate motor nameplate frequency rating.

FIGURE 18 – MOTOR HORSEPOWER SELECTION

	KBAC-24D		KBAC-27D				
	1	2**	3/4	1½**	KBAC-29*	KBAC-45*	KBAC-48*
□	3/4	1	1/2	1	A 3***	3	5
□	1/2	3/4	1/4	3/4	B 2***	2	3
□	1/4	1/2	1/8	1/4	C 1½	1½	2
□					D 1	1	1½
□					E 3/4	3/4	1

The factory setting is shown in bold.
Jumper J2 on Models KBAC-29, 45, 48 is labeled “A”, “B”, “C”, “D”, “E”. **Model KBAC-27D is rated 1½ HP maximum with 115 Volt AC line input and 2 HP maximum with 208/230 Volt AC line input. *Model KBAC-29 is rated 2 HP maximum with single-phase AC line input and 3 HP maximum with 3-phase AC line input.*

- 6.4.1 **SETTING THE DRIVE FOR 60 Hz OR 50 Hz MOTOR OPERATION –**
The drive is factory set to operate 60 Hz motors. Jumper J4 is factory set to the “1X” position and Jumper J5 is factory set to the “60Hz” position. For 50 Hz motors, set Jumper J5 to the “50Hz” position, and be sure Jumper J4 is set to the “1X” position. See Figure 20.

FIGURE 19 – AUTOMATIC RIDE-THROUGH OR MANUAL START SELECTION*

Automatic Ride-Through (Factory Setting) (J3 Installed in “A” Position)	Manual Start (J3 Installed in “M” Position)

**On Model KBAC-24D, Jumper J3 is labeled “AUTO” and “MAN”.*

- 6.4.2 **SETTING THE DRIVE FOR TWO TIMES THE RATED MOTOR RPM –**
The drive can also be used to operate the motor up to two times the rated RPM. However, constant horsepower will result when operating the drive in the “2X” mode above the motor rated frequency. See Figure 21, on page 18.

FIGURE 20 – 60 Hz & 50 Hz MOTOR SELECTION

60 Hz Motor Operation (Factory Setting) (J4 Installed in “1X” Position) (J5 Installed in “60Hz” Position)		50 Hz Motor Operation (J4 Installed in “1X” Position) (J5 Installed in “50Hz” Position)	

For 120 Hz output with 60 Hz motor, set Jumper J4 to the “2X” position and be sure Jumper J5 is set to the “60Hz” position. For 100 Hz output with 50 Hz motor, set Jumper J4 to the “2X” position and set Jumper J5 to the “50Hz” position. See Figure 22, on page 18.

6.5 BOOST MODE SELECTION (J6) –

Jumper J6 is factory set to the “FIX” position for Fixed Boost. For Adjustable Boost using the BOOST Trimpot, set Jumper J6 to the “ADJ” position. See Figure 23. Also see Section 12.8, on pages 24 – 25, for the BOOST Trimpot range.

6.6 BRAKING MODE SELECTION (J7) –

Jumper J7 is factory set to the “RG” position for Regenerative Braking when the Start/Stop Switch is set to the “STOP” position. For DC Injection Braking, set Jumper J7 to the “INJ” position. See Figure 24. Also see Section 12.5, on page 23.

When the Injection Brake Mode is selected, the DECEL Trimpot is used to adjust the brake time and intensity.

6.7 RUN/FAULT OUTPUT RELAY

OPERATION SELECTION (J8) –
Jumper J8 is factory set to the “R” position for “Run” operation of the Run/Fault Relay. For “Fault” operation of the Run/Fault Relay, set Jumper J8 to the “F” position. See Figure 25, on page 19.

For Run/Fault Relay output contacts, see Section 5.8, on pages 15 – 16. The Run/Fault Relay contact status for various drive operating conditions is shown in Table 6, on page 16.

6.8 STOP CONTACT SELECTION (J9) –

Jumper J9 is factory set to the “NO” position for a normally open stop contact. For remote normally closed stop contact, set Jumper J9 to the “NC” position. See Figure 26, on page 19. For wiring information, see Section 5.5, on pages 14 – 15.

6.9 TORQUE MODE SELECTION (J10) –

Jumper J10 is factory set to the “CT” position for Constant Torque Mode, which is desirable for most machine applications. For Variable Torque Mode, used for HVAC and fan applications, set Jumper J10 to the “VT” position. See Figure 27, on page 19.

6.10 I²t OVERLOAD SELECTION (J11) – Jumper J11 is factory set to the “1” position for Inverter Duty Rated Motors. For Non Inverter Duty Rated Motors and HVAC applications, set Jumper J11 to the “2” position. See Figure 28, on page 19. Also see Section 12.7, on page 24.

FIGURE 21 – AVAILABLE TORQUE vs. OUTPUT FREQUENCY




FIGURE 22

120 Hz & 100 Hz DRIVE OUTPUT FREQUENCY SELECTION

120 Hz Output with 60 Hz Motor (J4 Installed in "2X" Position) (J5 Installed in "60Hz" Position)		100 Hz Output with 50 Hz Motor (J4 Installed in "2X" Position) (J5 Installed in "50Hz" Position)	

FIGURE 23 – FIXED OR ADJUSTABLE BOOST SELECTION

Fixed Boost (Factory Setting) (J6 Installed in "FIX" Position)	Adjustable Boost (J6 Installed in "ADJ" Position)

FIGURE 24 – REGENERATIVE OR DC INJECTION BRAKING SELECTION

Regenerative Braking (Factory Setting) (J7 Installed in "RG" Position)	DC Injection Braking (J7 Installed in "INJ" Position)

7 MOUNTING INSTRUCTIONS

It is recommended that the drive be mounted vertically on a flat surface with adequate ventilation. Leave enough room below the drive to allow for AC line, motor connections, and any other wiring that is required. Although the drive is designed for outdoor and washdown use, care should be taken to avoid extreme hazardous locations where physical damage can occur. When mounting the drive in an enclosure, the enclosure should be large enough to allow for proper heat dissipation so that the ambient temperature does not exceed 45 °C (113 °F) at full rating. See Figures 3 and 4, on page 11.

 **WARNING! Do not use this drive in an explosion-proof application.**

8 RECOMMENDED HIGH VOLTAGE DIELECTRIC WITHSTAND TESTING (HI-POT TESTING)

Testing agencies such as UL, CSA, VDE, etc., usually require that equipment undergo a hi-pot test. In order to prevent catastrophic damage to the drive which has been installed in the equipment, the following procedure is recommended. A typical hi-pot test setup is shown in Figure 29, on page 20. **All drives have been factory hi-pot tested in accordance with UL requirements.**

 **WARNING! All equipment AC line inputs must be disconnected from the AC power.**

8.1 Connect all equipment AC power input lines together and connect them to the H.V. lead of the hi-pot tester. Connect the RETURN lead of the hi-pot tester to the frame on which the drive and other auxiliary equipment are mounted.

8.2 The hi-pot tester must have an automatic ramp-up to the test voltage and an automatic ramp-down to zero voltage.

Note: If the hi-pot tester does not have automatic ramping, then the hi-pot output must be manually increased to the test voltage and then manually reduced to zero. This procedure must be followed for each machine to be tested. A suggested hi-pot tester is Slaughter Model 2550.

CAUTION! Instantly applying the hi-pot voltage will cause irreversible damage to the drive, which will void the warranty.

FIGURE 25 – “RUN” OR “FAULT”
OUTPUT RELAY OPERATION SELECTION

“Run” Output Relay Operation (Factory Setting) (J8 Installed in “R” Position)	“Fault” Output Relay Operation (J8 Installed in “F” Position)
	

FIGURE 26 – NORMALLY OPEN
OR CLOSED STOP CONTACT SELECTION

Normally Open Stop Contact (Factory Setting) (J9 Installed in “NO” Position)	Normally Closed Stop Contact (J9 Installed in “NC” Position)
	


FIGURE 27 – CONSTANT OR VARIABLE TORQUE SELECTION

Constant Torque (Factory Setting) (J10 Installed in “CT” Position)	Variable Torque (J10 Installed in “VT” Position)
	

FIGURE 28 – I²t OVERLOAD SELECTION

Inverter Duty Rated Motor (Factory Setting) (J11 Installed in “1” Position)	Non Inverter Duty Rated Motor Operation (J11 Installed in “2” Position)
	

FIGURE 29 – TYPICAL HI-POT TEST SETUP



9 DRIVE OPERATION

- 9.1 START-UP PROCEDURE** – After the drive has been properly setup (jumpers and trimpots set to the desired positions) and wiring completed, the start-up procedure can begin. If the AC power has been properly brought to the drive, the power (PWR) LED will illuminate green. The status (ST) LED will indicate drive status, as described in Section 11.2.

To start the drive, momentarily set the Start/Stop Switch to the “START” position. The motor will begin to accelerate to the set speed.



WARNING! Using a jumper to eliminate the start/stop function will cause the motor to run at the Main Speed Potentiometer setting when the AC line is applied. See Section 9.2.

Note: If the motor rotates in the incorrect direction, it will be necessary to disconnect the AC line, reverse any two motor leads, and repeat the start-up procedure.

- 9.2 STARTING THE DRIVE AFTER A FAULT HAS BEEN CLEARED^{1,2}** – The drive monitors four faults (Undervoltage, Overvoltage, Short Circuit (at the motor (phase-to-phase)), and Overload). See Section 11.2 for the Status (ST) LED indication. Also see Section 6.3, on page 17, for Automatic Ride-Through or Manual Restart selection with Jumper J3.

To start the drive after a fault has been cleared, use the Start/Stop Switch^{2,3}.

If the Start/Stop Switch has been eliminated (bypassed), see Section 5.6, on page 15.⁴ The drive can be started (after the fault has been cleared), by disconnecting the AC power until all LEDs are no longer illuminated and then reconnecting the AC power.

Notes: **1.** For an Overload Fault, be sure the fault has been cleared before restarting the drive. Check the motor current with an AC RMS responding ammeter. Also, the CL setting may be set too low. See Section 12.7, on page 24. **2.** For an Overvoltage Fault, if the drive is set for Automatic Ride-Through, the drive will automatically restart when the AC line voltage returns to below the specified Overvoltage Trip Point. **3.** If the Forward-Stop-Reverse Switch has been installed, it can be used to restart the drive. **4.** If the Start/Stop Switch has been eliminated (bypassed), the AC line must be used to start the drive after an Overload Fault has been cleared.

10 AC LINE FUSING

The drive does not contain line fuses. Most electrical codes require that each ungrounded conductor contain circuit protection. **Do not fuse neutral or ground connections.** It is recommended to install a fuse (Littelfuse 312/314, Buss ABC, or equivalent) or a circuit breaker in series with each ungrounded conductor. **Do not fuse motor leads.** For the recommended fuse size, see Table 4, on page 10.

Wire the drive in accordance with the National Electrical Code requirements and other local codes that may apply to the application.

11 DIAGNOSTIC LEDS

The drive contains two diagnostic LEDs mounted on the enclosure cover to display the drive's operational status.

- 11.1 POWER ON LED (PWR)** – The “PWR” LED will illuminate green when the AC line is applied to the drive.



WARNING! Do not depend on the PWR LED as a guaranteed power off condition. Be sure the main power switch or circuit breaker is in the “OFF” position before servicing this drive.

- 11.2 STATUS LED (ST)** – The “ST” LED is a tricolor LED which provides indication of a fault or abnormal condition. The information provided can be used to diagnose an installation problem such as incorrect input voltage, overload condition, and drive output miswiring. It also provides a signal which informs

the user that all drive and microcontroller operating parameters are normal. Table 7, summarizes the “ST” LED functions.

TABLE 7 – DRIVE OPERATING CONDITION AND STATUS LED INDICATOR

Drive Operating Condition	Flash Rate ¹ and LED Color
Normal Operation	Slow Flash Green
Overload (120% – 160% Full Load)	Steady Red ²
I ² t (Drive Timed Out)	Quick Flash Red ²
Short Circuit	Slow Flash Red
Undervoltage	Quick Flash Red / Yellow ³
Overvoltage	Slow Flash Red / Yellow ³
Stop	Steady Yellow
Stand-By ⁴	Slow Flash Yellow

Notes: 1. Slow Flash = 1 second on and 1 second off. Quick Flash = 0.25 second on and 0.25 second off. 2. When the Overload is removed, before the I²t times out and trips the drive, the “ST” LED will flash green. 3. When the Undervoltage or Overvoltage condition is corrected, the “ST” LED will flash Red / Yellow / Green. 4. Only if the Forward-Stop-Reverse Switch is installed.

12 TRIMPOT ADJUSTMENTS

The drive contains trimpots which are factory set for most applications. See Figure 2, on page 9, for the location of the trimpots and their approximate factory calibrated positions. Some applications may require readjustment of the trimpots in order to tailor the drive for a specific requirement. The trimpots may be readjusted as described below.



WARNING! If possible, do not adjust trimpots with the main power applied. If adjustments are made with the main power applied, an insulated adjustment tool must be used and safety glasses must be worn. High voltage exists in this drive. Fire and/or electrocution can result if caution is not exercised. Safety Warning, on page 5, must be read and understood before proceeding.

12.1 MINIMUM SPEED (MIN) – Sets the minimum speed of the motor. The MIN Trimpot is factory set to 0% of frequency setting. For a higher minimum speed setting, rotate the MIN Trimpot clockwise. See Figure 30.

12.2 MAXIMUM SPEED (MAX) – Sets the maximum speed of the motor. The MAX Trimpot is factory set to 100% of frequency setting. For a lower maximum speed setting, rotate the MAX Trimpot counterclockwise. For a higher maximum speed setting, rotate the MAX Trimpot clockwise. See Figure 31.

12.3 ACCELERATION (ACCEL) – Sets the amount of time for the motor to accelerate from zero speed to full speed. The ACCEL Trimpot is factory set to 1.5 seconds. For a longer acceleration time, rotate the ACCEL Trimpot clockwise. For more rapid acceleration, rotate the ACCEL Trimpot counterclockwise. See Figure 32.

Note: Rapid acceleration settings may cause the current limit circuit to activate, which will extend the acceleration time.

FIGURE 30 – MINIMUM SPEED TRIMPOT RANGE




FIGURE 31 – MAXIMUM SPEED TRIMPOT RANGE





FIGURE 32 – ACCELERATION TRIMPOT RANGE



- 12.4 DECELERATION (DECEL)** – Sets the amount of time for the motor to decelerate from full speed to zero speed. The DECEL Trimpot is factory set to 1.5 seconds. For longer deceleration time, rotate the DECEL Trimpot clockwise. For more rapid deceleration, rotate the DECEL Trimpot counterclockwise. See Figure 33.

Application Note – On applications with high inertial loads, the deceleration may automatically increase in time. This will slow down the rate of speed of decrease to prevent the bus voltage from rising to the Overvoltage Trip point. This function is called Regeneration Protection. **It is recommended that for very high inertial loads that both the ACCEL and DECEL Trimpots be set to greater than 10 seconds.**

- 12.5 DC INJECTION BRAKE (DECEL)** – The drive is factory set for Regenerative Braking (Jumper J7 set to the “RG” position). When the drive is set for DC Injection Brake (Jumper J7 set to the “INJ” position), the DECEL trimpot is used to set the DC Injection Brake voltage and time. See Figure 34. Also see Section 6.6, on page 18.

The DC Injection Brake voltage and time range is 10% of full drive output voltage for 3 seconds with the trimpot fully clockwise and 25% of full drive output voltage for 1 second with the trimpot fully counterclockwise. Models KBAC-24D, 27D, 29 are factory set for 49 Volts for 1.2 seconds and Models KBAC-45, 48 are factory set for 98 Volts for 1.2 seconds.

Adjust the trimpot so that the load stops within the required time.

- 12.6 SLIP COMPENSATION (COMP)** – Sets the amount of Volts/Hz to maintain set motor speed under varying loads. The COMP Trimpot is factory set to 1.5 Volts/Hz, which provides excellent speed regulation for most motors. To increase the slip compensation, rotate the COMP Trimpot clockwise. To decrease the slip compensation, rotate the COMP Trimpot counterclockwise. See Figure 35.

The slip compensation may be adjusted as follows:

1. Wire an AC RMS ammeter in series with one motor phase.
2. Run the motor and set the unloaded speed to approximately 50% (900 RPM on 4-pole 1500/1725 RPM motors).
3. Using a tachometer, record the unloaded speed.
4. Load the motor to the nameplate rated current (AC Amps).
5. Adjust the COMP Trimpot until the loaded RPM is equal to the unloaded RPM.
6. The motor is now compensated to provide constant speed under varying loads.

FIGURE 33 – DECELERATION TRIMPOT RANGE




FIGURE 34 – DC INJECTION BRAKE TRIMPOT RANGE




FIGURE 35 – SLIP COMPENSATION TRIMPOT RANGE





FIGURE 36 – CURRENT LIMIT TRIMPOT RANGE



12.7 MOTOR OVERLOAD (I^2t) WITH RMS CURRENT LIMIT (CL)* – Sets the current limit (overload), which limits the maximum current to the motor, which prevents motor burnout and eliminates nuisance trips. The CL Trimpot is factory set to 160% of the drive rated current. To increase the current limit, rotate the CL Trimpot clockwise. To decrease the current limit, rotate the CL Trimpot counterclockwise. See Figure 36, on page 23, and Figure 37.

**UL approved as an electronic overload protector for motors.*

CAUTION! Adjusting the current limit above 160% of the motor nameplate rating can cause overheating of the motor. Consult the motor manufacturer. Do not leave the motor in a locked rotor condition for more than a few seconds since motor damage may occur.


In order to ensure that the motor is properly protected with the I^2t feature, it is required that the CL Trimpot be set for 160% of the motor nameplate rated current, as described below.

Note: This adjustment must be made within 6 seconds or the I^2t Trip will occur.

The current limit may be adjusted as follows:

1. Connect an AC RMS ammeter in series with one motor phase.
2. Set the CL Trimpot fully counterclockwise.
3. Adjust the speed setting to 30%.
4. Lock the motor shaft and adjust the CL Trimpot to 160% of the motor nameplate rated current.

FIGURE 37 – I^2t TRIP TIME vs. MOTOR CURRENT



12.8 BOOST (BOOST) – The drive is factory set for Fixed Boost (Jumper J6 set to the “FIX” position). When the drive is set for Adjustable Boost (Jumper J6 set to the “ADJ” position), the BOOST Trimpot can be used to adjust the amount of boost voltage to the motor. See Figure 38, on page 25. Also see Section 6.5, on page 18.

Application Note – The Boost function operates over a frequency range of 0 – 15 Hz. If the frequency range required is above 15 Hz, Boost adjustment is not necessary.

WARNING! To avoid motor winding overheating and failure, do not overboost the motor.

Note: An unloaded motor with excessive boost will draw more current than a partially loaded motor.

The boost voltage may be adjusted as follows:

1. Wire an AC RMS ammeter in series with one motor phase.
2. Run the motor unloaded at approximately 4 Hz (or 120 RPM).
3. Increase the boost until the ammeter reaches the motor nameplate rated current (Amps AC).
4. Using the Main Speed Potentiometer, slowly adjust the motor speed over a 1 – 15 Hz (0 – 450 RPM) range. If the motor current exceeds the nameplate rating, decrease the boost setting.

12.9 JOG (JOG) – The Jog feature requires the installation of a Run-Stop-Jog Switch. The switch must be wired according to Figure 39. The JOG Trimpot range is shown in Figure 40.

The orange Main Speed Potentiometer wire (wiper) which connects to Terminal “P2” on the drive must be removed and installed on Terminal “RUN” on the switch. The “JOG” Terminal on the drive connects to “JOG” on the switch. Terminal “P2” on the drive connects to the center (common) terminal on the switch.

When the switch is in the “JOG” position, the JOG Trimpot is used to set the “jog” speed. When the switch is in the “RUN” position, the Main Speed Potentiometer is used for speed setting.

The Run-Stop-Jog Switch (Part No. 9340) is available as an optional accessory. See Table 2, on page 8.

FIGURE 38 – BOOST TRIMPOT RANGE




FIGURE 39 – RUN-STOP-JOG SWITCH CONNECTION (SPDT – CENTER OFF)





FIGURE 40 – JOG TRIMPOT RANGE



– NOTES –

LIMITED WARRANTY

For a period of 18 months from the date of original purchase, KB Electronics, Inc. will repair or replace without charge, devices which our examination proves to be defective in material or workmanship. This warranty is valid if the unit has not been tampered with by unauthorized persons, misused, abused, or improperly installed and has been used in accordance with the instructions and/or ratings supplied. The foregoing is in lieu of any other warranty or guarantee, expressed or implied. KB Electronics, Inc. is not responsible for any expense, including installation and removal, inconvenience, or consequential damage, including injury to any person, caused by items of our manufacture or sale. Some states do not allow certain exclusions or limitations found in this warranty and therefore they may not apply to you. In any event, the total liability of KB Electronics, Inc., under any circumstance, shall not exceed the full purchase price of this product. (rev 2/2000)

COPYRIGHT © 2008 KB Electronics, Inc.

All rights reserved. In accordance with the United States Copyright Act of 1976, no part of this publication may be reproduced in any form or by any means without permission in writing from KB Electronics, Inc. (8/2002)



KB ELECTRONICS, INC.

12095 NW 39th Street, Coral Springs, FL 33065-2516 • (954) 346-4900 • FAX (954) 346-3377
Outside Florida Call Toll Free (800) 221-6570 • info@kbelectronics.com
www.kbelectronics.com